

North Star XT Tent Pitching Instructions





Kathmandu

Please follow these instructions. Failure to do so may void the warranty.
For more detailed information, check the instruction manual.

FEATURES


- ▶ Tent inner and fly
- ▶ 18 Aluminium Alloy Pegs
- ▶ 4 x DAC Featherlite NSL Alloy Poles
- ▶ 10 x Guy Lines
- ▶ Tent compression stuff sack
- ▶ Peg and pole bags
- ▶ Repair kit: Fabric patches, pole repair section, spare fly SR buckle

1 - Prep




Lay out the inner and secure one upwind corner. Carefully assemble the poles, making sure all joints are fully inserted. Thread the grey poles into the pole sleeves marked with grey and the red poles into the sleeves marked with red.

2 - Inner



Insert the end of one grey pole into its corresponding corner eyelet. Bend the pole and insert the other end into its eyelet. Repeat with the other grey pole then with both red poles. Clip the inner to the poles.

3 - Fly



Drape the fly over the inner. To make sure the guy fins are secure, check all Velcro tabs are fastened to the pole sleeves. Clip together and tension all fly quick-release buckles.

4 - Pegging Out



Position the tent and peg one vestibule through the bungee loops then tension the tent along its length and peg down the other end. Make sure the inner is evenly tensioned and the floor lies flat. Peg the sides down. Peg out the guys, at least one metre from the tent. Check that the fly is not touching the inner.

CARE INSTRUCTIONS

This tent can be damaged by petrol, kerosene, alcohol, detergents and aerosols such as fly spray and deodorants. Do not machine wash. Do not use bleach. Clean off dirt with a damp cloth and mild soap.

STORAGE

Only store your tent when it is completely dry. If possible, store the tent loose so that air can circulate. Before storing, empty all pockets and carefully close all zips. Store all poles and pegs separately in the bags provided.